

# INSTALLATION INSTRUCTIONS

## BRICK

**These instructions are used for the following brick-in letterbox:**

**- 187 Palazzo Front Open**

1. Detach front panel by loosening the nuts that secures it.
2. Insert the sleeve into the front mounting frame until the four locking notches and corresponding locking tabs click together.
3. Insert the sleeve into the rear cap until it fits within comfortably
4. Build brickwork up to desired height and set letterbox in place
5. Complete remaining brickwork and allow all mortar and render to set.
6. Re-attach the front door to the front mounting frame with the nuts provided.
7. Your letterbox is ready to use.

