

INSTALLATION INSTRUCTIONS

BRICK - PAPER HOLDERS

Please use these instructions as a general guide for the following brick-in paper holder sets:

- Classic Raw
- Classic Black
- 170 Milano
- 174 Milano Black
- BR03
- BR29 Kew (CRM, GRA, BLK)

1. Cut a piece of 100mm PVC pipe to the desired length.
2. Join the paper holders with the pipe on both ends and seal with silicone.
3. Build brickwork up to desired height. Lay mortar and place paper holder into the desired position.
6. Complete remaining brickwork around paper holder set.

