

INSTALLATION INSTRUCTIONS

TIMBER FENCE

These instructions are used for the following timber fence letterbox:
- 810 Palazzo

Tools Required:

- Drill
- Jigsaw
- Pencil

1. Place mounting guide in the desired location on your fence
2. Push through the guide with a pencil to mark the mail-slot area to be cut and stud holes to drill
3. Cut out the mail opening and drill two 8mm holes for the front panel mounting studs
4. Fit the front panel so its mounting studs pass through the holes just drilled
5. Attach the letterbox to the mounting studs through the letterboxes' upper mounting holes.
6. Fit nuts to the mounting studs and tighten.
7. Finish by screwing letterbox to fence through the lower mounting holes accessed through the back door.

