


Monza Letterbox

56 Northgate Drive, Thomastown VIC 3043 www.milkcan.com.au support@milkcan.com.au (03) 9464 6964

244




You will need to install the Monza letterbox in a location that is easily accessible to Australia Post and couriers. This will typically be at your front boundary. The ideal height for the mail opening is 90-120cm from the ground.

Installation


Installing into a timber fence


- 1. Open the back door, reach through and remove the front panel by unscrewing the nuts.
- 2. Measure the letterbox body and cut a slightly larger hole into the fence.



3. Slide the letterbox body in through the <u>front</u> of the fence. Screw it to the fence with the screws provided (for hardwood, its easier if you pre-drill the screw holes).

MOUNTING STUDS MUST BE ON THIS SIDE






Installing into a brick wall


- 1. Open the back door, reach through and remove the front panel by unscrewing the nuts.
- 2. Build the brickwork up to the desired height and set the letterbox body in place following these guidelines;


IMPORTANT: STUDS MUST SIT TO LEFT SIDE OF THE LETTERBOX


- For <u>plain brick walls</u>, the front flanges should sit flush with the wall
- For <u>rendered walls</u>, set the front flanges so they will sit <u>flush</u> with the finished rendered surface.















(03) 9464 6964



Monza Letterbox

Attaching the Front Panel

- 1. Insert the locking arm by placing it through the guide slot.
- 2. Align the hinge holes with the corresponding studs. Secure the hinge using the nuts provided.



Parcel Delivery Instructions

This letterbox is specially designed to allow parcel delivery. The courier simply enters the allocated combination code to unlock the front door, places the parcel inside, closes the door and re-toggles the combination.

When you purchase an item to be delivered, let the supplier know the parcel delivery instruction. For example, "PLACE IN LETTERBOX. USE CODE 321 TO OPEN".